


12 PHYSICS

INVESTIGATION: STRENGTH OF EARTH'S MAGNETIC FIELD

AIM To determine the magnetic field strength of the Earth.

METHOD 1. Set up the following circuit with the thick copper wire aligned N - S in the Earth's field.



2. Arrange the wire at a set distance above the compass. Record this distance.
3. Place a 1.00 A current through the wire and record the deflection (θ_1).
4. Reverse the direction of the current and record θ_2 .
5. Repeat for several other currents up to 5.00 A.
6. Graph $\tan \theta$ against I and use it to determine the Earth's magnetic field strength.


BACKGROUND

The magnetic field of a wire is given by:

$$B_I = \frac{\mu_0 I}{2\pi d}$$

where $\mu_0 = 4\pi \times 10^{-7} \text{ NA}^{-2}$.

This field is at right angles to the wire, and will be at right angles to the horizontal component of the Earth's field.



The relationship between B_I and B_E becomes the following.

$$\tan \theta = \frac{B_I}{B_E} = \frac{\mu_0 I}{2\pi d B_E \cos 66^\circ}$$

RESULTS

I (A)	θ_1	θ_2	Average θ	$\tan \theta$

DISCUSSION Consider the following points.

- Sources of error.
- Accuracy compared to expected result.

CONCLUSION Write a suitable conclusion.